

# INSTRUCTIONS FOR THE NEW CRESTRON MEDIA IN STRANAHAN



**THIS IS FOR ROOM USE ONLY! ANY QUESTIONS, PROBLEMS,  
OR FOR ADDITIONAL COPIES CALL X 4607.**

## Starting Up

- If the Crestron screen is black then touch the Crestron screen to turn it on.



- When the UT picture is displayed, then touch the screen to begin.



- Projector will warm up for about 60 seconds - **Please Be Patient**, a light should illuminate in the projector.




- A menu screen of devices will appear on the Crestron screen.




## IF THE MONITOR IS OFF...

- Make sure the power button is green. This is located on the upper right hand side of the monitor.



- Also check to make sure that the computer is on by checking to see if the power button is green.



# HOST COMPUTER

- To display the host computer on the projector, touch the Host Computer button.




- To login to the Host Computer press “Ctrl Alt Delete” simultaneously.
- Your login screen will appear. Type in your username and password and make sure the “Log on to” is set to UTAD.




- Do not forget to logoff when you are finished.

# GUEST COMPUTER

- Located on the desktop is the caddy.



- Inside the caddy are 2 electrical outlets, an audio cable, VGA cable, and an Ethernet cable for the guest computer.




- Make sure that the VGA cable is plugged into your laptop.
- To view your laptop through the projector, push the Guest Computer button.




## FOR CABLE TV


- When you push the Cable Tuner button, cable television will automatically start.



- To adjust the volume, use the Volume Up and Volume Dn buttons on the Crestron touch screen.



- To change the television channels, touch the CH+ and CH- buttons on the Crestron touch screen.




# DOCUMENT CAMERA


- The Wolf Vision is now used in place of the overhead projector. It can read 8x11 sheets of paper, transparencies, and any printed material you want to project.



- Located near the working surface area of the Wolf Vision are the brightness and power options. Make sure the power is on as indicated by a green light.



- Place your document on the Wolf Vision working surface area.



- To zoom or focus in on your documents, use the buttons located by the camera head.



- To collapse the Wolf Vision pull the arm ring gently towards you.



## FOR DVD USE

- Press the OPEN/CLOSE button on the Optiplex 755 tower and insert the DVD.



- A screen will appear that will allow you to use the appropriate program for your application.



## SHUT DOWN

- At the end of your class, please turn off the projector. To do this, touch the Off button located in the bottom left side of the Crestron touch screen.



- Touch YES when asked if you are sure that you want to turn the system off. This will approximately take 2 minutes to shutdown and cool off.

